

SUPERNOVA

Art. H161-GC - Goldkontaktstecker

Universelle vergoldete Steckverbinder mit Crimpröhrchen. Komplettsset: 2 Steckern, 2 Buchsen, Schrumpfschläuche. Benötigtes Werkzeug: Abisolierzange, Crimpzange, Heißluftföhn, oder entsprechende Alternativen.



Installation (bitte vor der Montage komplett durchlesen):

1. Kabel auf gleiche Länge zuschneiden. Der Stecker hat später eine Gesamtlänge von ca. 40 mm.
2. Kabel auf 10 mm Länge vom schwarzen Schrumpfschlauch befreien. Die Enden 5 mm weit abisolieren.
3. Dicken Schrumpfschlauch weit auf das Kabel schieben. BITTE NICHT VERGESSEN! Später geht es nicht mehr.
4. Steckverbinder auf das Kabel schieben. Auf eine Litze einen Stecker, auf die andere ein Buchse.
5. Das Crimpröhrchen des Steckers zuerst an der Außenseite zusammendrücken, dann noch einmal weiter innen. Geeignetes Crimpwerkzeug verwenden.
6. 18 mm- Schrumpfschlauch bis zum Rand des drehbaren Lamellentils („Schneebeesen“) vorschieben; dann den 28 mm Stecker bis knapp über den Rand der Buchse, da er auch in Längsrichtung schrumpft. Vorsichtig mit einem Heißluftföhn erhitzen (oder sehr vorsichtig mit Feuerzeug). 80-130 ° C Schrumpftemp.
7. Den dicken Schrumpfschlauch wieder nach vorne über die schieben, so daß die Stecker ein umschumpft sind.
8. Auf der anderen Seite wiederholen, mit gegengleicher Anncrimpung von Stecker/Buchse. Beim Rücklicht muß unbedingt auf die Polarität geachtet werden!

www.supernova-lights.com

SUPERNOVA

Art. H161-GC - Gold Connectors

Universal gold-coated quick release connectors made in Germany. With integrated crimp tube. Set of 2 male and 2 female connectors & shrink tubes. Tools required: wire stripper, crimp tool, hot air blower or suitable substitutes.



Installation (please read completely before starting):

1. Cut the cables to length (both the same). The connector will have a length of ca. 50 mm [2 in].
2. Remove the black shrink tube from the cables 10 mm deep and strip 5 mm off the insulation on each end.
3. Slide the thicker shrink tube far onto the cable. PLEASE DON'T FORGET THIS! It won't be possible, later.
4. Slide the gold connectors onto the cables. Pair one male connector with one female.
5. Crimp the crimp tube near the edge first, then a little bit inwards. Use an appropriate, blunt crimping tool.
6. Slide the thin 18 mm shrink tube over the male connector so that it just reaches the "eggbeater" spring, then slide the 28 mm shrink tube onto the female connector, letting it overlap a little. Shrink them carefully with a hot air blower or *very* carefully with a lighter. The shrink temp. is 80-130 ° C [180-270 ° F]
7. Slide the thicker shrink tube back over the Y-section so that part of the connectors is covered and shrink it.
8. Repeat on the other side, with an inverted installation of the male an female connectors. When connecting our rear light, the polarity must not be mixed!

www.supernova-lights.com, Germany

Inhalt / Content



1. & 2.

*Zuschneiden & abisolieren
Cut to length & strip*

3.

*Dicken Schrumpfschlauch aufschieben !!!
Slide thicker shrink tube on cable !!!*

4. & 5.



6.



7.



8.

